

Setting Date/Time/Day

This operation is possible from the Administrator station or attendant consoles and enables you to set the date, time, and day.

► To set the date

1. Press a [DN] + #651 , with the handset on-hook.	You hear a confirmation tone.	#651 ENTER DATE
2. Enter the date (YYMMDD).		1 ENTER DATE 970524
3. Press Redial .	You hear a confirmation tone.	NO. NNN MAY 24 MON 12: 05
4. Press Spkr .	The telephone returns to the idle mode.	

► To set the time

1. Press [DN] + #652 , with the handset on-hook.	You hear a confirmation tone.	#652 ENTER TIME
2. Enter the time (HHMMSS) in the 24-hour clock format.	H=hour, M=minute and S=seconds. Use leading zeros: 060530 = 6:05AM and 30 seconds; 143045 = 2:30PM and 45 seconds.	51 ENTER TIME 120500

3. Press **Redial**.

You hear a confirmation tone.

NO. NNN
MAY 24 MON 12: 05

4. Press **Spkr**.

The telephone returns to the idle mode.

► To set the day of the week

1. Press a [DN] + **#653**, with the handset on-hook.

You hear a confirmation tone.

#653 ENTER DAY

2. Enter the number which corresponds to the appropriate day of the week:

#653 ENTER DAY 2

- 1** = Sunday
- 2** = Monday
- 3** = Tuesday
- 4** = Wednesday
- 5** = Thursday
- 6** = Friday
- 7** = Saturday

3. Press **Redial**.

You hear a confirmation tone.

NO. NNN
MAY 24 MON 12: 05

4. Press **Spkr**.

The telephone returns to the idle mode.